



The System



Installation & Scrubbing



PEST CONTROL INSULATION
SYSTEMS

PO Box 25 • Homer, GA 30547

T•A•P Wall Spray System

Once you have a blower system such as a K450 or larger, entering the high-margin market of new home construction is easy with the addition of our wall spray system components:

High-Pressure Pump Set: This unit comes with motorized electric pump with gauge, fittings, 150' of flexible high pressure hose and a 2 ½ " spray nozzle with spray tips.

The spray nozzle connects to your existing blowing hose (see crawlspace system). A source of water (tank or garden hose) is required.

Stud Scrubber: The electric stud scrubber is extended so 9 foot walls can be scrubbed without a ladder. The stud scrubber removes excess T•A•P from blown walls so that sheet rock can be applied to the studs.(see photo)

Pneumatic Staple Gun & Staples: In new homes, T•A•P is applied both before sheetrock (walls) and after sheetrock (ceilings), and it is necessary to net common, vault, & knee walls, and sometimes garage ceilings since there will be no access after sheetrock is applied. This package includes a high speed Senco staple gun designed to work with any common air compressor.

Netting: Our nine foot light weight netting (in rolls of 750') works best for new construction jobs since most walls are nine feet in height.

T•A•P Wall Spray System

- High-Pressure Pump Set complete w/ gauges & fittings
- Flexible High Pressure Hose (150')
- Wall Spray Nozzle w/ Jets

Ongoing Support

- Membership access @ www.TAPinsulation.com
- Training Manuals (electronic or printed upon purchase)
- Phone Support from PCIS
- Updated supply catalogs
- Warranty and product information for homeowners
- Quote sheets and sales support literature
- On-site training available (just pay the trainer's travel costs).
- Approximate delivery – Two weeks from order

T•A•P – *"Helps keep bugs out--and comfort in"*™



www.TAPinsulation.com

©PCISV0806